

MAZDA	ออโต้ (Auto)	ธรรมดา (Manual)	ออโต้ (Push Start)	ธรรมดา (Push Start)
MAZDA 2 '15/ CX-3 '15	-	-	✓	-
MAZDA 3 '14/ CX-5 '13	-	-	✓	-
BT-50 PRO '12	✓	✓	-	-
BT-50	✓	✓	-	-
MAZDA 2 '10-'13	✓	-	-	-